



assembly instructions

1-Use a clean cloth to wipe down the section of wall where the clock is to be installed.

2-Remove the adhesive backing and stick the case to the Wall, or alternatively use the center hole to screw it into place.

3-Close the case and install the hands: first insert the hour hand (smaller hand) followed by the minute hand (larger hand) by pushing them carefully onto the clock's spindle.

4-Set both hands at 12 o'clock.

5-To mark the hours use the template you will find enclosed.

a)Insert the open edge of the template over the clock's central spindle, between the two hands, then make a mark on the wall, using the hole which corresponds to the position of the hour hand.

b)To make the next mark, turn the minute hand 360° and the hour hand will automatically move on the correct position. Repeat this until you have made all twelve marks.

6-Remove the adhesive backing from the numbers and stick them in place.